JVC

SERVICE MANUAL

COLOUR TELEVISION

BASIC CHASSIS
CG

AV-21ATG

This service manual mainly consists of the following items:
• The items which differ from those for the AV-21AT service manual.
• The initial value for each setting item.
For details other than those described in this manual, please refer to the following service manual.
Reference Service Manual: AV-21AT Service Manual (No. 56013, May 2000)

Note: The page in parentheses shows the one for the AV-21AT service manual (No. 56013, May 2000).

HOW TO IDENTIFY MODEL

While referring to the illustration given below, identify model name on the rating label affixed to the rear cover.

COPYRIGHT © 2000 VICTOR COMPANY OF JAPAN, LTD.

No. 56014
May 2000

PARTS DIFFERENCE TABLE

The different parts between AV-21AT and AV-21ATG are described below:

⚠	REF. NO.	AV-21AT PART No.	AV-21ATG PART No.	PART NAME	DESCRIPTION
■ EXPLODED VIEW PARTS LIST (Page 28)					
⚠	15	LC20377-010A-H	**LC20377-001A-H**	RATING LABEL	
■ PRINTED WIRING BOARD PARTS LIST (Page 30)					
	—	SCG-1247A-H2	**SCG-1244A-H2**	MAIN PWB ASSY	
	IC1701	MN1873287JA	**MN1873287JB**	IC (MICROCOMPUTER)	
	IC1702	AT24C08-21FTR	**AT24C08-21FM**	IC (MEMORY)	(Service)
■ PACKING PARTS LIST (Page 34)					
	1	GG10056-017A-H	**GG10056-018A-H**	PACKING CASE	
⚠	7	LCT0748-001A-H	**LCT0728-001A-H**	INST BOOK	
⚠	8	LCT0749-001A-H	**LCT0729-001A-H**	DIGEST MANUAL	

SPECIFICATIONS (Page 2)

Item		Content
Dimensions (W × H × D)		502mm × 451mm × 480.5mm
Mass		19.5kg
TV RF System		B / G, I, D / K, K1
Colour System	TV Mode	PAL / SECAM
	VIDEO Mode	PAL / SECAM / NTSC3.58 / NTSC4.43
Receiving Frequency	VHF (VL)	46.25MHz ~ 168.25MHz
	VHF (VH)	175.25MHz ~ 463.25MHz
	UHF	471.25MHz ~ 863.25MHz
	CATV	● Cable TVs of Mid (X-Z, S1-S10) Super (S11-S20) & Hyper (S21-S41) bands receivable
Intermediate Frequency	VIF Carrier	38.0MHz
	SIF Carrier	31.5MHz (6.5MHz) 32.0MHz (6.0MHz) 32.5MHz (5.5MHz) 33.5MHz (4.5MHz)
Colour Sub Carrier Frequency		PAL (4.43MHz) SECAM (4.40625MHz / 4.25MHz) NTSC (3.58MHz / 4.43MHz)
Aerial Input Terminal		75Ω Unbalanced
Power Input		AC110 ~ 240V, 50 / 60Hz
Power Consumption		105W (Max.)/68W (Avg.)
Picture Tube		Visible size : 51cm measured diagonally
High Voltage		26.5kV ± 1.5kV (at zero beam current)
Speaker		5cm × 9 cm Oval type × 2
Audio Output		5W (Monaural)
Input	Video	1Vp-p, 75Ω
	Audio	500mVrms (–4dBs), High impedance
Output	Video	1Vp-p, 75Ω
	Audio	500mVrms (–4dBs), Low impedance
Headphone Jack		Stereo mini jack (3.5ø)
Remote Control Unit		RM-C364-1H (Battery size : AA/R06/UM-3 × 2)

Design & specifications are subject to change without notice.

SPECIFIC SERVICE INSTRUCTIONS

SETTING OF SYSTEM CONSTANT SET (Page 7)

Table 1

Setting item	Setting contents	Setting value
COLOUR	→ MULTI. → TRIPLE → PAL →	TRIPLE
BILINGUAL	→ YES → NO →	NO
TUNER	→ MU → MA →	MU
ECO SENSOR	→ YES → NO →	YES
LANGUAGE	→ E/R/A/F → E/A/F → E/A → E/F →	E/R/A/F
B/B SOUND	→ ON → OFF →	OFF
LOCK	YES ↔ 10 ↔ 20 ↔ ... ↔ 230 ↔ 240 ↔ 250	180
COLOUR AUTO	→ YES → NO →	NO
QSS	→ MINT → MQSS →	MINT
ALC	→ YES → NO →	NO
TEXT RATE	10 ↔ 20 ↔ 40 ↔ 80	20
AMP TUNER	→ YES → NO →	NO

USER SETTING VALUES (Page 7)

Table 2

Setting item	Setting value	Setting item	Setting value
SUB POWER	ON	PICTURE MODE (VSM)	BRIGHT
CHANNEL POSITION	1 POSITION	VNR	OFF
CHANNEL PRESET	Refer to OPERATING INSTRUCTION	OFF TIMER	OFF
		LANGUAGE	ENGLISH
VOLUME	Appropriate sound volume	AUTO SHUTOFF	OFF
TV/VIDEO	TV	ECO SENSOR	OFF
ON SCREEN DISPLAY	POSITION NUMBER DISPLAY	BLUE BACK	OFF
COLOUR SYSTEM	AUTO PAL	ON TIMER	PR1 0:00
SOUND SYSTEM	B / G	CHILD LOCK	OFF

SERVICE ADJUSTMENTS

■ Initial Setting Value

■ IF CIRCUIT ADJUSTMENT -- Adjustment of DELAY POINT (Page 15)

Setting (Adjustment) Item	Variable range	Initial setting value
DELAY POINT (AGC TAKE-OVER)	0 ~ 127	43

■ V/C (VIDEO/CHROMA) CIRCUIT ADJUSTMENT (Page 15)

[SUB MENU 2. V/C]

Setting item \ Colour system		Variable range	Initial setting value			
			PAL	SECAM	NTSC 3.58	NTSC 4.43
1. CUT OFF (R / G / B)		–128 ~ +127	–50	←	←	←
2. DRIVE (R / B)		–64 ~ +63	0	←	←	←
3. BRIGHT		–128 ~ +127	0	←	←	←
4. CONT.		–64 ~ +63	0	←	←	←
5. COLOUR (P / S / N3 / N4)		–64 ~ +63	0	←	←	←
6. TINT (N3 / N4)	TV / VIDEO	–64 ~ +63	———	———	0 / 0	0 / 0
7. SECAM BL ADJUST		–32 ~ +31	0	←	←	←
8. SHARP	TV / VIDEO	–32 ~ +31	–5 / +15	←	←	←

: Do not adjust.

Adjustment of SUB COLOUR-II (Page 18)

Adjustment part	Description
5. COLOUR	
PAL COLOUR	Value **(A)** in the figure: Set to **+12V (W & G)**.
SECAM COLOUR	Value **(A)** in the figure: Set to **+9V (W & G)**.
NTSC 3.58 COLOUR	Value **(A)** in the figure: Set to **+7V (W & G)**.

Adjustment of SUB TINT-II (Page 19)

Adjustment part	Description
6. TINT	
NTSC 3.58 TINT	Value **(B)** in the figure: Set to **+7V (W & Cy).**

■ DEFLECTION CIRCUIT ADJUSTMENT (Page 20)

[SUB MENU 4. DEF]

Setting item	Adjustment name	Variable range	Initial setting value	
			50Hz	60Hz
1. VER. POSITION	Vertical center	–4 ~ +3	–1	–3
2. HOR. POSITION	Horizontal center	–16 ~ +15	+3	+3
3. VER. HEIGHT	Vertical height	–64 ~ +63	–35	+1
4. VER. LINEARITY	Vertical linearity	–32 ~ +31	+15	–1
5. VER. SCURVE	Vertical scurve	–32 ~ +31	–32	0
6. HOR. VCO ADJUST	Horizontal VCO	–64 ~ +63	0	0

: Do not adjust.

■ VSM PRESET ADJUSTMENT (Page 22)

[Setting Values for SUB MENU 4. VSM PRESET]

VSM preset mode / VSM Setting item	BRIGHT	STANDARD	SOFT
TINT SETTING VALUE	+15	←	←
COLOUR SETTING VALUE	+15	←	←
BRIGHT SETTING VALUE	+15	←	←
CONT. SETTING VALUE	+30	+15	+11
SHARP SETTING VALUE	+15	+15	+12

: Do not adjust.

■ PRESET ADJUSTMENT (Page 23)

[SUB MENU 5. PRESET]

Setting item \ Colour system		Initial setting value			
		PAL	SECAM	NTSC 3.58	NTSC 4.43
1. C-TRAP FIX		1	←	←	←
2. SHARP PEAK		0	←	←	←
3. ABL		1	←	←	←
4. GAMMA		0	←	←	←
5. Y.DELAY TIME	TV	0	2	2	3
	VIDEO	0	2	0	2
6. BLACK EXP START		3	←	←	←
7. C-BPF	TV	1	←	0	←
	VIDEO	1	←	←	←
8. CW/SCP		0	←	←	←
9. V.IF DET. LEVEL		0	←	←	←
11. IF AGC MIN.		0	←	←	←
12. V.IF AGC		0	←	←	←
13. V.IF PMOD		0	←	←	←
19. VNR		15	←	←	←
20. RGB LIM.		1	←	←	←
21. RGB LIMIT LEVEL		2	←	←	←
23. TEXT H. POSITION		–3	←	←	←
24. READ DATA		———	———	———	———

: Do not adjust.

Setting item \ TV RF system	Initial setting value			
	B/G	I	D/K	M
10. S.IF DET. LEVEL	0	←	←	←
14. S.IF BPF BW ADJUST	0	←	←	←
15. S.IF TRAP FO ADJUST	0	←	←	←
16. S.IF TRAP FO ADJUST 2	0	←	←	←
17. S.IF-TRAP	0	←	←	←
18. S.IF-BPF	0	←	←	1
22. S.IF SW	1	←	←	0

: Do not adjust.